



Museum Textile Services

Frame/Shadowbox Installation

- Note: the rings on the hanging bracket are located approx 4 inches down from the top of the box, make sure to take this in to consideration when deciding on wall placement.
- The length of the entire box is 83 ½ inches, the center point of the box is at 41 ¾ inches – mark the center point on the wall.
- On each side of the center point measure out 40 ¾ inches and mark the wall – these will correspond to the top screw placement.
- Now measure down 11 inches from the top screw markings – these will correspond to the bottom screw placement – make sure all marks are square and parallel.
- Put 4 dry wall anchors in the four places marked.
- Install 4 screws in to the dry wall anchors leaving approx 3/16 inch of the screw threads exposed for the D-ring to rest on.
- Carefully lift the box with the help of at least one other person. Place the two top D-rings on their screws and then place the two lower D-rings on their screws. Gently release the box.
- NB: A cleat system can be purchased from MTS in the event that your wall is not strong enough to hold screws with drywall anchors. Hanging this box by any other means, such as a wire, will lead to failure.